

dbx® di4 Quick Start

1. On the mixer channels that you will be connecting the di4 to, lower the faders and gain/trim controls, then enable the mutes.
2. Turn the di4's *LEVEL* controls fully counter-clockwise, set all *ATTENUATION* switches to *0* and *GROUND* switches to *ON*, then connect the di4 using the diagram to the right for reference.
3. Connect the included power adapter to the power input jack.
4. Unmute the mixer channels, set the faders to unity gain (0), then raise the gain/trim controls until the desired level is achieved without distortion. If distortion is present, set the di4 channel's *ATTENUATION* switch to '-20'. If further attenuation is required to eliminate the distortion try the '-40' setting.
5. If a ground hum occurs on a di4 channel, set the channel's *GROUND* switch to '*LIFT*'.
6. If using the *AUX OUT* and/or *PHONE* jacks for monitoring, adjust the *LEVEL*, *PAN*, and *PHONE* controls accordingly.

Product Registration

Register your product at http://dbxpro.com/en-US/support/warranty_registration or scan the code to the right with a QR scanner app on your mobile device to go straight to web URL.



Download The Owner's Manual

Get the owner's manual at <http://dbxpro.com/en-US/products/di4#documentation> or scan the code to the right with a QR scanner app on your mobile device to go straight to web URL.

