Pioneer DJ

DJM-S7

Scratch-Style 2-Channel Performance DJ Mixer

- Familiar and clear hardware interface
- MAGVEL FADER PRO
- Large Performance Pads
- Large effect levers
- Bluetooth input
- Loop MIDI
- Built-in USB hub
- Scratch Bank
- Combo Pad mode
- Plug and play with Serato DJ Pro or rekordbox

serato DJ Pro | rekordbox

TURNTABLI7M

Pioneer DJ

DJM-S7 SCRATCH-STYLE 2-CHANNEL PERFORMANCE DJ MIXER

Express your individuality

SPECIFICATIONS

Software		rekordbox Serato DJ Pro
Bluetooth Audio Input	Version	Bluetooth standard version 5.0
	Supported Codecs	SBC, AAC, Qualcomm® aptX™, Qualcomm® aptX™ Low Latency
	Maximum Communication Distance	Approximately 10 m in unobstructed circumstances*
Frequency response		20 Hz – 20 kHz
S/N Ratio		110 dB (USB) 103 dB (LINE) 88 dB (PHONO) 80 dB (MIC) 103 dB (AUX)
Total Harmonic Distortion		0.003% (USB) 0.005% (LINE)
Input/Output Terminals	Inputs	LINE x 2 (RCA) PHONO x 2 (RCA) MIC x 1 (XLR & 1/4-inch TRS jack) AUX x 1 (RCA)
	Outputs	MASTER x 2 (XLR, RCA) BOOTH x 1 (1/4-inch TRS jack) HEADPHONES x 2 (1/4-inch stereo jack, 3.5-mm stereo mini jack)
	USB	USB (Type A) x 2 USB (Type B) x 2
Power Supply		AC 100 – 240 V, 50 Hz / 60 Hz
Power Consumption		24 W
Maximum Dimensions (W x D x H)		267.0 x 397.4 x 107.9 mm / 10.51" x 15.65" x 4.25"
Weight		4.5 kg / 9.9 lb
Accessories		Power cord USB cable Warranty (for some regions) Quick Start Guide Precautions for Use Serato DJ Pro Expansion Pack voucher (Pitch 'n Time DJ)

Visit the official Serato DJ Pro website for its specifications: **serato.com**
Visit the official rekordbox website for its specifications: **rekordbox.com**

PRODUCT FEATURES

FAMILIAR AND CLEAR HARDWARE INTERFACE
With a familiar and clear layout, the DJM-S7 gives you the freedom to play energetically and bring your own style to every performance.

MAGVEL FADER PRO
We've enhanced the feeling of the MAGVEL FADER PRO and boosted the rigidity of the knob mounting shaft in the vertical direction by 30 percent so you can scratch with even more confidence.

BLUETOOTH INPUT
Pair your tablet or mobile device with the DJM-S7 via Bluetooth and drop sounds straight into your set. You can play the audio directly through the master output or either of the channels and use the dedicated knob and fader on the front of the mixer to adjust the level.

LOOP MIDI
Control various functions in your DJ application by repeatedly sending a MIDI signal to the software in a set beat cycle. Use the Beat buttons on the mixer to set the length of the loop, then switch on the effect lever to trigger the relevant feature, e.g., Hot Cue, sampler, or key shift-up.

SCRATCH BANK
Instantly load scratch samples from 4 banks you've assigned in Serato DJ Pro by simply tapping a pad. You can load from a specified start point too – handy if you want to drop in full tracks during a routine.

COMBO PAD MODE
Activate Combo Pad mode in Serato DJ Pro to use 2 different pad modes simultaneously, e.g., Hot Cue and Sampler.

PIONEERDJ.COM