

Studiomaster



Studiomaster
PAS

Studiomaster

PS

**USER
GUIDE**



INDEX

INDEX

- 1 Introduction
- 1 Read the User Guide
- 1 Unpacking

- 2 Safety Instructions

- 3 Technical Specification

- 4 Warranty
- 5 Service Information



INTRODUCTION

Thank you for buying this Studiomaster product.

The PAS/PS range of compact powered and unpowered speakers are ideal for anywhere you need a clear, responsive and compact sounds system.

The PAS8 and PAS6 feature a built in 50W amplifier with volume and EQ (tone) control.

All PAS/PS speakers come complete with wall mounting brackets.

READ THE USER GUIDE

The PAS/PS range are very easy to use, although to get the best from your new purchase, we recommend you read this User Guide before getting down to any serious work.

It also contains important safety information.

UNPACKING

Remove your Studiomaster product from its packaging and ensure that along with this User Guide you have an A.C. power cord / mains lead (PAS models only) and a warranty card.

Retain the packing carton in the eventuality that the unit needs to be returned for service or repair, and please complete and return your warranty card. Returning the completed warranty card does not diminish your statutory rights in any way.

WEEE Mark



If you want to dispose of this product, do not mix with general household waste. There are separate collection systems for used electronic products in accordance with legislation under the WEEE Directive (Directive 2002/96/EC) and is effective only within the European Union.



SAFETY INSTRUCTIONS

READ THIS BEFORE YOU USE YOUR PRODUCT

1. (PAS MODELS ONLY) Before connecting the A.C. power cord make sure the Voltage selector (located on the side of the unit) is set to your local supply voltage. For supplies between 220 and 240V use the 230V position. For supplies between 110 and 120V use the 115V position.
2. (PAS MODELS ONLY) Only use the A.C. power cord / mains lead supplied with the product. Replace if it becomes damaged in any way.
3. (PAS MODELS ONLY) Never operate without, or remove the safety ground (earth) from the A.C. power cord / mains lead.
4. Do not attempt to remove any screws or panels. There are no user serviceable parts inside.
5. Do not operate the unit next to heat sources such as radiators.
6. The unit should not be operated or stored near rain or moisture.
7. This equipment must not be exposed to dripping or splashing and no objects filled with liquids should be placed on top of it.
8. Write the serial number in the box provided in the Warranty section for future reference.
9. If the unit gets damaged, has been dropped or appears to have developed a fault refer to the Service Information section for details.

WARNING (PAS MODELS ONLY)
THIS APPARATUS MUST BE EARTHED (GROUNDED)

WARNING

THESE PRODUCTS ARE CAPABLE OF VERY HIGH VOLUME LEVELS AND PROLONGED EXPOSURE CAN RESULT IN HEARING DAMAGE



TECHNICAL SPECIFICATION

FACTS & FIGURES

	PAS6	PAS8	PS6	PS8	
Speaker HF Unit	6" High Output Design High Frequency Tweeter	8" High Output Design High Frequency Tweeter	6" High Output Design High Frequency Tweeter	8" High Output Design High Frequency Tweeter	
Finish	Black Moulded Plastic	Black Moulded Plastic	Black Moulded Plastic	Black Moulded Plastic	
Power Output 1% THD Power	50W -	50W -	- 50W	- 50W	
Distortion (amp)	30W @ 8ohms - 0.01%	30W @ 8ohms - 0.01%	-	-	
Power Supply	230V range +/-10% ~50/60Hz 115V range +/-10% ~50/60Hz				
Size (w x h x d)	metric imperial	230mm x 360mm x 220mm 9.1" x 14.2" x 8.7"	280mm x 410mm x 250mm 11" x 16.1" x 9.8"	230mm x 360mm x 220mm 9.1" x 14.2" x 8.7"	280mm x 410mm x 250mm 11" x 16.1" x 9.8"
Weight (net) Weight (shipping)	5kg (11lb) 6kg (13.2lb)	6kg (13.2lb) 7kg (15.4lb)	4kg (8.8lb) 5kg (11lb)	5kg (11lb) 6kg (13.2lb)	



WARRANTY

ARE YOU COVERED?

The Manufacturer warrants all Studiomaser products to be free from defects in materials and workmanship for a period of one year from date of purchase. The Manufacturer reserves the right to the final decision on all warranty claims.

Exclusions to Warranty Cover

Damage caused by accident, misuse, improper installation or neglect.

Damage caused by repair, modification or service by persons not authorised by Studiomaser.

Products on which the serial number has been defaced, altered or removed.

Who is Protected

This warranty is enforceable by the original purchaser and any subsequent owner(s) during the warranty period, providing a

copy of the original sales receipt is submitted whenever a warranty service is required.

It is recommended that you complete and mail the Warranty Registration Card supplied with your product.

For your reference in the event of a warranty or service repair, please complete the following information and attach a copy of your original sales receipt.

Model : _____

Serial Number : _____

Purchase Date : _____

Purchased From : _____

Note : THIS WARRANTY DOES NOT AFFECT YOUR STATUTORY RIGHTS



SERVICE INFORMATION

HOW TO GET MY PRODUCT REPAIRED

If you have a problem with your Studiomaster product or think it has developed a fault you should first carefully check the Trouble Shooting section in this guide. If this does not solve the problem or if the product is physically damaged, contact your local dealer or distributor for service details.

Should it be recommended you return the product to your nearest Studiomaster Service Centre you must first contact them.

You will be asked for the product type and serial number. You will then be given a Returns Authorisation (RA) number.

Pack the unit in its original carton to protect it from shipping damage.


You must have the Returns Authorisation number clearly marked on the outside of the carton or we may refuse the delivery. Studiomaster cannot be held responsible for damage resulting from the equipment being packed incorrectly.

Label the equipment clearly with your name and address and include a clear description of the fault. The more information you supply helps the service engineer, minimising repair cost when out of warranty.

Important : No liability will be accepted by Studiomaster for any transit damage to units not returned in their original packing, for warranty repairs or otherwise.

In Accordance with our progressive product development, Studiomaster / Studioking Limited reserve the right to change features and specifications without prior notice.

EXPECT THE BEST



Studioking Limited

**7 Eden Way, Pages Industrial Park, Leighton Buzzard, Bedfordshire LU7 4TZ UK
Tel : 44 (0)1525 217111 Fax : 44 (0)1525 378466 Email : enquiries@studiomaster.com**

www.studiomaster.com

MADE IN CHINA