



NEXO

VNT-ADPT

PS8 / PS10 / PS15 ADAPTER for FLYING ACCESSORIES.
(Not Required for PS10 R2 and PS15 R2)




1



PS8

Remove the 2 cap screws.


HEXALOBULAR SOCKET
FLAT HEAD SCREWS
M5x20 (TORX n°25)



PS10

Remove the 5 cap screws.

HEXALOBULAR SOCKET
LOW HEAD CAP SCREWS
M6x10 (TORX n°30)




PS15

Remove the 4 cap screws.


HEXALOBULAR SOCKET
LOW HEAD CAP SCREWS
M6x10 (TORX n°30)

2



Stick the adhesive sealing gasket on adapter. (Only PS10 & PS15)


3



PS8

Use the 2 screws supplied.


HEXALOBULAR SOCKET
LOW HEAD CAP SCREWS
M5x25 (TORX n°25)



PS10

Use the 2 screws supplied.

HEXALOBULAR SOCKET
LOW HEAD CAP SCREWS
M6x20 (TORX n°30)



PS15

Use the 2 screws supplied.

HEXALOBULAR SOCKET
LOW HEAD CAP SCREWS
M6x20 (TORX n°30)

CONTENTS




WARNING :
Screws must be secured using Loctite 243™

x1



x1



x2

M6x20



x2

M5x25

