



FUZE SPOT™

user manual

©2023 ELATION PROFESSIONAL all rights reserved. Information, specifications, diagrams, images, and instructions herein are subject to change without notice. ELATION PROFESSIONAL logo and identifying product names and numbers herein are trademarks of ELATION PROFESSIONAL. Copyright protection claimed includes all forms and matters of copyrightable materials and information now allowed by statutory or judicial law or hereinafter granted. Product names used in this document may be trademarks or registered trademarks of their respective companies and are hereby acknowledged. All non-ELATION brands and product names are trademarks or registered trademarks of their respective companies.

ELATION PROFESSIONAL and all affiliated companies hereby disclaim all liabilities for property, equipment, building, and electrical damages, injuries to any persons, and direct or indirect economic loss associated with the use or reliance of any information contained within this document, and/or because of the improper, unsafe, insufficient, and negligent assembly, installation, rigging, and operation of this product.

Elation Professional USA | 6122 S. Eastern Ave. | Los Angeles, CA. 90040 323-582-3322 | 323-832-9142 fax | www.elationlighting.com | info@elationlighting.com

Elation Professional B.V. | Junostraat 2 | 6468 EW Kerkrade, The Netherlands +31 45 546 85 66 | +31 45 546 85 96 fax | www.elationlighting.eu | info@elationlighting.eu

Elation Professional Mexico | AV Santa Ana 30 | Parque Industrial Lerma, Lerma, Mexico 52000 +52 (728) 282-7070

DOCUMENT VERSION



Due to additional product features and/or enhancements, an updated version of this document may be available online. Please scan the QR Code with your mobile device or visit www.elationlighting.com for the latest revision/update of this manual before installation and/or programming.

Date	Document	Software	DMX	Notes		
Date	Version	Version ≥	Channel Modes	Notes		
08/15/19	1.0	1.0.3	(RGBMA 31 / 41)	Initial release.		
00/13/17	110	11013	(CMY 29 / 37)	in clar releaser		
08/27/19	1.1	N/C	NO CHANGE	Updated default DMX values for RGBMA.		
05/12/20	1.2	N/C	NO CHANGE	Updated Installation Instructions.		
07/20/20	1.3	N/C	NO CHANGE	Updated thermal		
08/10/20	1.4	N/C	NO CHANGE	Updated color temp		
10/09/20	1.5	1.09	NO CHANGE	Updated specifications, and		
10/03/20	1.5	1.05	NO CHANGE	primary/secondary modes		
03/10/21	1.6	1.0.10	NO CHANGE	Updated System Menu, DMX Traits		
05/12/23	1.7	N/C	NO CHANGE	Added software updating information		

CONTENTS

General Information	4
Limited Warranty (USA Only)	5
Safety Guidelines	6
Maintenance Guidelines	8
Overview	9
Colors	10
Gobos and Animation Wheels	11
Custom Gobos	12
Gobo Replacement	13
Snoot Installation	17
Installation	18
System Menu	22
Color LED Programming Guidelines	26
DMX Traits	27
Remote Device Management (RDM)	35
Color Temperature Table	36
Virtual Gel Swatch Book Table	37
Error Codes	38
Specifications	39
Dimensional Drawings	40
Optional Accessories FCC Statement	42

GENERAL INFORMATION

FOR PROFESSIONAL USE ONLY

INTRODUCTION

Please read and understand the instructions in this manual carefully and thoroughly before attempting to operate this device. These instructions contain important safety and use information.

UNACKING

Every device has been thoroughly tested and has been shipped in perfect operating condition. Carefully check the shipping carton for damage that may have occurred during shipping. If the carton is damaged, carefully inspect the device for damage, and be sure all accessories necessary to install and operate the device have arrived intact. In the event damage has been found or parts are missing, please contact our customer support team for further instructions. Please do not return this device to your dealer without first contacting customer support. Please do not discard the shipping carton in the trash. Please recycle whenever possible.

BOX CONTENTS

Snoot

Omega Brackets (x2)

Twist Locking Power Connector (x1)

CUSTOMER SUPPORT

Contact **ELATION Service** for any product related service and support needs. Also visit **forums.elationlighting.com** with questions, comments, or suggestions. ELATION SERVICE USA - Monday - Friday 8:00am to 4:30pm PST **323-582-3322** | Fax 323-832-9142 | support@elationlighting.com

ELATION SERVICE EUROPE - Monday - Friday 08:30 to 17:00 CET +31 45 546 85 63 | Fax +31 45 546 85 96 | support@elationlighting.eu

REPLACEMENT PARTS please visit parts.elationlighting.com

It is strongly recommended to power the fixture down completely when not in use. Doing so will reduce wear on the fixture due to sustained or extended operational periods, thereby maximizing its operational lifespan.

LIMITED WARRANTY (USA ONLY)

- A. Elation Professional hereby warrants, to the original purchaser, Elation Professional products to be free of manufacturing defects in material and workmanship for a period of two years (730 days), and Elation Professional product rechargeable batteries to be free of manufacturing defects in material and workmanship for a period of six months (180 days), from the original date of purchase. This warranty excludes discharge lamps and all product accessories. This warranty shall be valid only if the product is purchased within the United States of America, including possessions and territories. It is the owner's responsibility to establish the date and place of purchase by acceptable evidence, at the time service is sought.
- B. For warranty service, send the product only to the Elation Professional factory. All shipping charges must be pre-paid. If the requested repairs or service (including parts replacement) are within the terms of this warranty, Elation Professional will pay return shipping charges only to a designated point within the United States. If any product is sent, it must be shipped in its original package and packaging material. No accessories should be shipped with the product. If any accessories are shipped with the product, Elation Professional shall have no liability whatsoever for loss and/or or damage to any such accessories, nor for the safe return thereof.
- C. This warranty is void if the product serial number and/or labels are altered or removed; if the product is modified in any manner which Elation Professional concludes, after inspection, affects the reliability of the product; if the product has been repaired or serviced by anyone other than the Elation Professional factory unless prior written authorization was issued to purchaser by Elation Professional; if the product is damaged because not properly maintained as set forth in the product instructions, guidelines and/or user manual.
- D. This is not a service contract, and this warranty does not include any maintenance, cleaning, or periodic check-up. During the periods as specified above, Elation Professional will replace defective parts at its expense, and will absorb all expenses for warranty service and repair labor by reason of defects in material or workmanship. The sole responsibility of Elation Professional under this warranty shall be limited to the repair of the product, or replacement thereof, including parts, at the sole discretion of Elation Professional. All products covered by this warranty were manufactured after January 1, 1990, and bare identifying marks to that effect.
- E. Elation Professional reserves the right to make changes in design and/or performance improvements upon its products without any obligation to include these changes in any products theretofore manufactured.
- F. No warranty, whether expressed or implied, is given or made with respect to any accessory supplied with the products described above. Except to the extent prohibited by applicable law, all implied warranties made by Elation Professional in connection with this product, including warranties of merchantability or fitness, are limited in duration to the warranty periods set forth above. And no warranties, whether expressed or implied, including warranties of merchantability or fitness, shall apply to this product after said periods have expired. The consumer's and/or dealer's sole remedy shall be such repair or replacement as is expressly provided above; and under no circumstances shall Elation Professional be liable for any loss and/or damage, direct and/or consequential, arising out of the use of, and/or the inability to use, this product.
- G. This warranty is the only written warranty applicable to Elation Professional products and supersedes all prior warranties and written descriptions of warranty terms and conditions heretofore published.

WARRANTY RETURNS

All returned service items whether under warranty or not, must be freight pre-paid and accompany a return authorization (R.A.) number. The R.A. number must be clearly written on the outside of the return package. A brief description of the problem as well as the R.A. number must also be written down on a piece of paper and included in the shipping container. If the unit is under warranty, you must provide a copy of your proof of purchase invoice. Items returned without a R.A. number clearly marked on the outside of the package will be refused and returned at customer's expense. You may obtain a R.A. number by contacting customer support.

SAFETY GUIDELINES

This fixture is a sophisticated piece of electronic equipment. To guarantee a smooth operation, it is important to follow all instructions and guidelines in this manual. Elation Professional is not responsible for injury and/or damages resulting from the misuse of this fixture due to the disregard of the information printed in this manual. Only qualified and/or certified personnel should perform installation of this fixture and only the original rigging parts (omega brackets) included with this fixture should be used for installation. Any modifications to the fixture and/or the included mounting hardware will void the original manufactures warranty and increase the risk of damage and/or personal injury.



PROTECTION CLASS 1 - FIXTURE MUST BE PROPERLY GROUNDED



THERE ARE NO USER SERVICEABLE PARTS INSIDE THIS UNIT.

DO NOT ATTEMPT ANY REPAIRS YOURSELF; DOING SO WILL VOID YOUR MANUFACUTER'S WARRANTY. DAMAGES RESULTING FROM MODIFICATIONS TO THIS FIXTURE AND/OR THE DISREGARD OF SAFETY INSTRUCTIONS AND GUIDELINES IN THIS MANUAL VOID THE MANUFACTURER'S WARRANTY, AND ARE NOT SUBJECT TO ANY WARRANTY CLAIMS AND/OR REPAIRS.



DO NOT PLUG FIXTURE INTO A DIMMER PACK!
NEVER OPEN THIS FIXTURE WHILE IN USE!
UNPLUG POWER BEFORE SERVICING FIXTURE!
NEVER TOUCH FIXTURE DURING OPERATION, AS IT MAY BE HOT!
KEEP FLAMMABLE MATERIALS AWAY FROM FIXTURE!



NEVER LOOK DIRECTLY INTO THE LIGHT SOURCE!
RETINA INJURY RISK - MAY INDUCE BLINDNESS!
SENSITIVE PERSONS MAY SUFFER AN EPILEPTIC SHOCK!



INDOOR / DRY LOCATIONS USE ONLY!
DO NOT EXPOSE FIXTURE TO RAIN AND MOISTURE!



MINIMUM DISTANCE TO OBJECTS/SURFACES
MUST BE 1.6 FOOT (0.5 METER)
MINIMUM DISTANCE OF INFLAMMABLE MATERIALS
FROM THE SURFACE 1.6 FEET (0.5 METER)
MAXIMUM AMBIENT OPERATING TEMPERATURE 113°F (45°C)

SAFETY GUIDELINES

DO NOT TOUCH the fixture housing during operation. Turn OFF the power and allow approximately 15 minutes for the fixture to cool down before serving.

DO NOT shake fixture, avoid brute force when installing and/or operating fixture.

DO NOT operate fixture if the power cord is frayed, crimped, damaged and/or if any of the power cord connectors are damaged and do not insert into the fixture securely with ease. NEVER force a power cord connector into the fixture. If the power cord or any of its connectors are damaged, replace it immediately with a new one of similar power rating.

DO NOT block any air ventilation slots.

All fan and air inlets must remain clean and never blocked.

Allow approx. 6" (15cm) between fixture and other devices or a wall for proper cooling.

Always disconnect fixture from main power source before performing any type of service and/or cleaning procedure. Only handle the power cord by the plug end, never pull out the plug by tugging the wire portion of the cord.

During the initial operation of this fixture, a light smoke or smell may emit from the interior of the fixture. This is a normal process and is caused by excess paint in the interior of the casing burning off from the heat associated with the lamp and will decrease gradually over time.

Consistent operational breaks will ensure fixture will function properly for many years.

ONLY use the original packaging and materials to transport the fixture in for service.

It is strongly recommended to power the fixture down completely when not in use. Doing so will reduce wear on the fixture due to sustained or extended operational periods, thereby maximizing its operational lifespan.

MAINTENANCE GUIDELINES



DISCONNECT POWER BEFORE PERFORMING ANY MAINTENANCE!

CLEANING

Frequent cleaning is recommended to insure proper function, optimized light output, and an extended life. The frequency of cleaning depends on the environment in which the fixture operates: damp, smoky or particularly dirty environments can cause greater accumulation of dirt on the fixture's optics. Clean the external lens surface at least every 20 days with a soft cloth to avoid dirt/debris accumulation.

NEVER use alcohol, solvents, or ammonia-based cleaners.

MAINTENANCE

Regular inspections are recommended to insure proper function and extended life.

There are no user serviceable parts inside this fixture, please refer all other service issues to an authorized Elation service technician. Should you need any spare parts, please order genuine parts from your local Elation dealer.

Please refer to the following points during routine inspections:


A detailed electric check by an approved electrical engineer every three months, to make sure the circuit contacts are in good condition and prevent overheating.

Be sure all screws and fasteners are always tightened securely. Lose screws may fall out during normal operation resulting in damage or injury as larger parts could fall.

Check for any deformations on the housing, color lenses, rigging hardware and rigging points (ceiling, suspension, trussing). Deformations in the housing could allow for dust to enter the fixture. Damaged rigging points or unsecured rigging could cause the fixture to fall and seriously injure a person(s).

Electric power supply cables must not show any damage, material fatigue or sediments. **NEVER** remove the ground prong from the power cable.

OVERVIEW



COLORS


Colors	Color Temperature	Green Shift
Cyan		
Magenta		Full Minus Green to Neutral
Yellow		
Red	2400K – 8500K	Neutral White
Green	2400K - 8300K	Neutrai Willte
Blue		
Mint		Neutral to Full Plus Green
Amber		

Virtual Gel Swatch Book Colors


7	Pale Yellow	157	Pink	68	Sky Blue
103	Straw	36	Medium Pink	143	Pale Navy Blue
151	Gold Tint	111	Dark Pink	131	Marine Blue
100	Spring Yellow	128	Bright Pink	115	Peacock Blue
10	Medium Yellow	148	Bright Rose	172	Lagoon Blue
101	Yellow	332	Special Rose Pink	116	Medium Blue Green
104	Deep Amber	793	Vanity Fair	90	Dark Yellow Green
15	Deep Straw	113	Magenta	139	Primary Green
179	Loving Amber	46	Dark Magenta	122	Fern Green
21	Gold Amber	48	Rose Purple	89	Moss Green
105	Orange	126	Mauve	124	Dark Green
158	Deep Orange	49	Medium Purple	88	Lime Green
22	Dark Amber	58	Lavender	138	Pale Green
778	Millennium Gold	199	Palace Blue	203	Quarter CT Blue
135	Deep Golden Amber	119	Dark Blue	202	Half CT Blue
24	Scarlet	132	Medium Blue	201	FULL CT Blue
106	Primary Red	120	Deep Blue	200	Double CT Blue
26	Bright Red	165	Daylight Blue	206	Quarter CT Orange
27	Medium Red	161	Slate Blue	205	Half CT Orange
19	Fire	118	Light Blue	204	FULL CT Orange

GOBOS AND ANIMATION WHEELS


INTERCHANGEABLE-ROTATING GLASS GOBO WHEEL 1




INTERCHANGEABLE-ROTATING GLASS GOBO WHEEL 2



ANIMATION WHEEL



CUSTOM GOBOS



FUZE SPOT ROTATING GLASS GOBOS - WHEELS 1 & 2						
Gobo O.D. (Max. Outer Diameter)	ф29.9mm					
Gobo I.D. (Max. Image Diameter)	ф25.0mm					
Gobo Holder Diameter	ф30.0mm					
Gobo Thickness	ф 1.1mm					
Gobo Material	High Temp Glass					
GODO Material	(Max 600C°)					

* * * IMPORTANT NOTICE REGARDING CUSTOM GOBOS * * *

Due to the high temperature optical system, special material as listed above is required for custom gobos. Due to varying manufacturing processes and tolerances, it is highly recommended to provide a gobo sample and holder from the fixture to the custom gobo vendor for accurate sizing. Extended testing of custom gobo designs is highly recommended prior to use. Contact ELATION SERVICE for further information.

ELATION SERVICE USA - Monday - Friday 8:00am to 4:30pm PST 323-582-3322 | Fax 323-832-9142 | support@elationlighting.com ELATION SERVICE EUROPE - Monday - Friday 08:30 to 17:00 CET +31 45 546 85 63 | Fax +31 45 546 85 96 | support@elationlighting.eu

GOBGOBO REPLACEMENT



1. Before removing covers, place fixture on a stable flat surface in an **INDOOR DUST FREE** location. Ensure moving head is locked into a neutral upright position with both **PAN** and **TILT** locks engaged.




2. Unfasten and remove the front back panels; each and with secured (4x)14-turn Phillips-head screws. (These screws are integrally installed in both panels and cannot be removed.) With the panel screws unfastened, unclip their safety cables to remove them completely from the fixture.






GOBO REPLACEMENT





3. The Control Module impedes the removal of the GOBO Wheel Module and will need to be removed to access the GOBO Wheel Module. The Control Module is secured to the fixture frame rail with (2x) slotted thumb screws.



4. To disconnect the Control Module, rotate the gimble to access the two connectors on opposite side.










5. Locate the 2-pin and 4-pin Control Module connectors and carefully unplug them from their connector bases. DO NOT USE FORCE TO REMOVE CONNECTORS!

GOBO REPLACEMENT





6. Impeding the removal of the Control Module is the lens housing of the Lens Module, which is set within the lens aperture. Lift the Lens Module to clear the lens housing from the lens aperture in the Control Module. With the Lens Module lifted, carefully grip the Control Module and slide it out and away to clear the mounting rails.





7. Locate the 4-pin GOBO Wheel Module connector and carefully unplug it from the connector base. DO NOT USE FORCE TO REMOVE CONNECTOR!





8. Loosen the (2x) slotted thumb screws that secure the GOBO Wheel Module.

GOBO REPLACEMENT



9. Carefully grip the GOBO Wheel module and slide it out and away to clear the mounting rails, and then carefully place the module on a stable flat surface in an **INDOOR DUST FREE** location.




10. REPLACING A ROTATING GOBO Locate the specific Rotating GOBO to replace. Carefully grip the GOBO Holder using your index finger and gently lift it slightly, and then with your fingers pull it out and away until it fully clears the GOBO Wheel. Now locate the tab of the spring, and with a precision pick (or similar tool), carefully press retaining spring inward to relieve tension.



11. Remove the retaining spring and carefully separate the GOBO from the GOBO Holder. Install the replacement Rotating GOBO following the steps above in reverse order.

CAUTION: TAKE CARE NOT TO SCRATCH GOBO OR GOBO HOLDER

SNOOT INSTALLATION



1. PLACE FIXTURE ON THE STABLE FLAT SURFACE AND LET COOL FOR 15MINS.

- 2. Align Snoot onto front lens so 4 screw holes on snoot match 4 screw holes on lens.
- 3. Carefully using a hand screwdriver, insert/secure included 4 screws.
- 4. Check Snoot to confirm it is seated properly and all 4 screws are secure.



DO NOT OVER TIGHTEN SCREWS! DO NOT USE A POWER SCREWDRIVER!



FLAMMABLE MATERIAL WARNING

Keep fixture minimum 5.0 feet (1.5m) away from flammable materials and/or pyrotechnics.



ELECTRICAL CONNECTIONS

A qualified electrician should be used for all electrical connections and/or installations.



USE CAUTION WHEN POWER LINKING OTHER MODEL FIXTURES AS THE POWER CONSUMPTION OF OTHER MODEL FIXTURES MAY EXCEED THE MAX POWER OUTPUT ON THIS FIXTURE. CHECK SILK SCREEN FOR MAX AMPS.



MINIMUM DISTANCE TO OBJECTS/SURFACES MUST BE 1 FOOT (0.3 METERS)



MINIMUM DISTANCE OF INFLAMMABLE MATERIALS FROM THE SURFACE 1.6 FEET (0.5 METER)



MAXIMUM AMBIENT TEMPERATURE 113° F (45°C)



DO NOT INSTALL THE FIXTURE IF YOU ARE NOT QUALIFIED TO DO SO!

Fixture **MUST** be installed following all local, national, and country commercial electrical and construction codes and regulations.

Before rigging/mounting a single fixture or multiple fixtures to any metal truss/structure or placing the fixture(s) on any surface, a professional equipment installer **MUST** be consulted to determine if the metal truss/structure or surface is properly certified to safely hold the combined weight of the fixture(s), clamps, cables, and accessories.

Overhead rigging requires extensive experience, including amongst others calculating working load limits, installation material being used, and periodic safety inspection of all installation material and the fixture. If you lack these qualifications, do not attempt the installation yourself. Improper installation can result in bodily injury.

Fixture(s) should be installed in areas outside walking paths, seating areas, or away from areas where unauthorized personnel might reach the fixture by hand.


NEVER stand directly below the fixture(s) when rigging, removing, or servicing.

Overhead fixture installation must always be secured with a secondary safety attachment, such as an appropriately rated safety cable.

Allow approximately 15 minutes for the fixture to cool down before serving.

OMEGA BRACKETS INSTALLATION

Insert the Omega Brackets into the matching holes on the bottom of the fixture. Secure the Omega Brackets to the fixture by turning each quick-lock fastener ¼ turn clockwise; making sure the fastener is completely locked. Omega Brackets can be installed into the fixture base as illustrated below.




CLAMP INSTALLATION

When mounting fixture to truss, be sure to secure an appropriately rated professional grade rigging clamp to the included **Omega Brackets** using an M10 screw fitted through the center hole of the **Omega Brackets**. The fixture provides a built-in rigging point for a **SAFETY CABLE**. Be sure to only use one of the designated rigging points for the safety cable and never secure a safety cable to a carrying handle.

RIGGING

Overhead rigging requires extensive experience, including among others calculating working load limits, installation material being used, and periodic safety inspection of all installation material and the fixture. If you lack these qualifications, do not attempt the installation yourself. Improper installation can result in bodily injury.





FALLING FIXTURES CAN CAUSE SEVERE INJURY OR SERIOUS EQUIPMENT DAMAGE! FOR THIS REASON, FIXTURES SHOULD BE INSTALLED AND INSPECTED ONLY BY QUALIFIED PERSONNEL. DO NOT INSTALL THE UNIT IF YOU LACK THE QUALIFICATIONS TO DO SO, OR IF YOU HAVE DOUBTS ABOUT THE SAFETY AND SECURITY OF THE INSTALLATION SETUP OR LOCATION!




ALWAYS ATTACH A SAFETY CABLE WHENEVER INSTALLING THIS FIXTURE IN A SUSPENDED ENVIRONMENT TO ENSURE THE FIXTURE WILL NOT FALL IF THE CLAMP FAILS.

POTENTIAL INTERNAL FIXTURE DAMAGE FROM EXTERNAL SOURCES OF LIGHT BEAMS

External sources of light beams from direct sunlight, lighting moving head fixtures, and lasers, which are focused directly towards the exterior housing and/or penetrate the front lens opening of ELATION lighting fixtures, can cause severe internal damage including burning to optics, dichroic color filters, glass and metal gobos, prisms, animation wheels, frost filters, iris, shutters, motors, belts, wiring, discharge lamps, and LEDs.


This issue is not specific only to ELATION lighting fixtures, it is a common issue with lighting fixtures from all manufacturers. Although there is no true way to fully prevent this issue from happening, the guidelines below can prevent any potential damage from occurring if followed. Contact ELATION Service for more details.

DO NOT EXPOSE THE FIXTURE AND/OR FRONT LENS OPENING TO LIGHT BEAMS FROM DIRECT SUNLIGHT, OTHER LIGHTING MOVING HEAD FIXTURES, AND LASERS WHILE UNPACKING, INSTALLATION, USE, AND EXTENDED IDLE TIMES OUTDOORS. DO NOT FOCUS A LIGHT BEAM FROM ONE LIGHTING FIXTURE DIRECTLY TOWARDS ANOTHER.



The fixture includes an easy to navigate system menu. The LCD touch panel display located on the front of the fixture (see image below), provides access to the main system menu and is where all necessary system adjustments are made to the fixture. During normal operation, pressing the ENTER (Check Mark) button once 5will access the fixture's main menu. Once in the main menu you can navigate through the different functions and access the sub-menus with the UP and DOWN buttons. Once you reach a field that requires adjusting, press the ENTER button to activate that field and use the UP and DOWN buttons to adjust the field. Pressing the ENTER button once more will confirm your setting. You may exit the main menu at any time without making any adjustments by pressing the ESC (Back Arrow) button.

To access the LCD Menu Control Display via the internal battery, press and hold the **BATTERY ICON** button for 3 seconds. The LCD Menu Control Display will shut **OFF** automatically about 1 minute from the last button press.





A USB FLASH DRIVE CAN BE USED TO UPDATE THE FIXTURE TO THE LATEST SOFTWARE. Using a USB Flash Drive loaded with the latest software, insert it into the USB Service Port, then navigate to PERSONALITY/SERVICE, enter the passcode (050), and select UPDATE SOFTWARE. A copy of the latest software can be obtained by contacting Elation Support.



AN ELATION C-LOADER II CAN ALSO BE USED TO UPDATE THE FIXTURE TO THE LATEST SOFTWARE. To order this device, please contact Elation Support for further details.

ELATION SERVICE USA - Monday - Friday 8:00am to 4:30pm PST 323-582-3322 | Fax 323-832-9142 | support@elationlighting.com

ELATION SERVICE EUROPE - Monday - Friday 08:30 to 17:00 CET +31 45 546 85 63 | Fax +31 45 546 85 96 | support@elationlighting.eu

	Supports S	Software Versions: ≥ 1	.0.10	
	DMX Address	A001 ~ AXXX		
DMX Settings	DMX Channel Mode	Standard, Extend		
	No DMX Status	Hold Last, Blackout, Ir	nternal Programs	
	Primary	ON / OFF		
	Secondary	ON / OFF		
Personality	Status Settings	Pan Invert Tilt Invert Pan/Tilt Feedback Pan Degree Pan/TiltSpeed Hibernation	ON / OFF ON / OFF ON / OFF 630/540 Speed 1 ~ 4 OFF/ 01M~99M, 15M	
	Fan Settings	Mute, Studio, Auto, Hi	igh, Silent	
	Dim Modes	Standard, Stage, TV, Architectural, Theatre, Stage 2, Dim Speed	Os, 0.1s, 0.2s, 0.3s, 0.4s, 0.5s, 0.6s, 0.7s, 0.8s, 0.9s, 1.0s, 1.5s, 2.0s, 3.0s, 4.0s, 5.0s, 6.0s, 7.0s, 8.0s, 9.0s, 10s	
	Dim Curves	Linear, Square, Square	Inverse, S-Curve	
	LED Refresh Rate	1200Hz , 900-1500Hz 5000Hz, 6000Hz, 10H 25KHz		
		Pan/Tilt Reset	YES / NO	
		Color Reset	YES / NO	
	Reset Motors	Gobo Reset	YES / NO	
		Focus and Zoom reset	YES / NO	
		Other motor reset	YES / NO	
		Screen Saver Delay	001 -10M/ OFF	
	Display	Touch Screen Lock	OFF/ON	
		Rotate Display 180°	YES / NO	
	Temp Unit	C / F		

3131611111	_140				
Personality (continued)	Service	Passcode = 050	Calibratiln KIKI Factory Restore	Pan Tilt Red Green Blue Mint Amber CTO Red CTO Green CTO Blue CTO Mint CTO Amber Gobo1 GoboRot1-1 GoboRot1-2 GoboRot1-3 GoboRot1-5 GoboRot1-6 Focus GoboRot1-1 Focus GoboRot1-2 Focus GoboRot1-3 Focus GoboRot1-5 Focus GoboRot1-6 Gobo2 GoboRot2-1 GoboRot2-2 GoboRot2-3 GoboRot2-3 GoboRot2-5 Focus GoboRot2-1 Focus GoboRot2-5 Focus GoboRot2-5 Focus GoboRot2-5 Focus GoboRot2-6 Animation RotAnimation Iris Prism1 Prism1Rot Frost Focus Zoom Yes / No	1. CTO Red··· CTO Amber are CTO color calibration. 2. GoboRot1-1 to 1-6 & GoboRot2-1 to 2-6 are for individual gobo direction calibration. 3. FocusGobo Rot1-1 to 1-6 and FocusGobo Rot2-1 to 2-6 are for calibration of individual gobo sharpness.

Manual Control	Pan Pan Fine Tilt Tilt Fine Red Color Control	000-255 000-255 000-255 000-255 000-255 000-255		
Internal Programs	Program 0	Speed	000-255	
		Fade	000-255	
	Program 1	Speed	000-255	-
		Fade	000-255	-
	Program 2	Speed	000-255	-
		Fade	000-255	-
	Program 3	Speed	000-255	
		Fade	000-255	-
				-
	Program 16	Speed	000-255	-
		Fade	000-255	
Information	Fixture Life Time	Power On Time	xxxxxx Hours	
	Fixture Last Run Time	ResetableTime	xxxxxx Hours	
		Power On Time Reset		
	Fixture	LED's	Current	xxx F / xxx C
	Temperatures		Max Resettable	xxx F / xxx C
			Max Not Resettable	xxx F / xxx C
		Reset LED Temp		
		Base Temp	Current	xxx F / xxx C
	Fan Info.	LED_fan RPM	1_Fan Standby	
			2_Fan Standby	
			3_Fan Standby	
			4_Fan Standby	
		Base_fan RPM	Base_Fan Standby	
	DMX Values	Pan, Tilt, …, Zoom	000-255	
	Product ID's	RDM UID	00000	
	Error Logs	Fixture Errors	Error1, Error2, ···	
	C (1)/	Reset Error Log	Passcode YES/ NO	
	Software Version	1U:V1.0.3 2U:V1.0.3 3U:V1.0.3 4U:V1.0.3 5U:V1.0.3 6U:V1.0.3		

COLOR LED PROGRAMMING GUIDELINES

The fixture utilizes an advanced additive LED light engine that contains Red, Green, Blue, Mint and Amber LED which when combined, provides a brilliant high CRI White. Using a 5-color LED engine allows the fixture to have a wide color gamut which offers robust saturated colors as well as a wide range of pastel and theatrical colors.

Programming a 5-color LED engine is a bit more time consuming than the more common 3-color CMY (Cyan, Yellow, Magenta) or RGB (Red, Blue Green) systems. To help ensure optimal performance of the fixture, it is highly suggested to try out the multiple DMX control modes to understand specifically how they work with color before programming a full show. A couple suggested modes are listed below.

The **CMY Extended** DMX control mode provides a "natural" color mix which is compatible with color pickers of most lighting consoles and includes 16-bit color control.

The **Extended** RGBMA (Red, Green, Blue, Mint, Amber) DMX control mode provides slightly higher precision color mixes but may be require additional time to find the right values for all 5-color LEDs to achieve a specific desired color.

DMX TRAITS

	MODE / CI			change w	ithout any prior written notice.	T	1
Standard	MODE / Ch Extended	CMY	CMY Extended	VALUE	FUNCTION	DEFAULT	SNAP
1	1	1	1		PAN Movement 8bit	127	
ı	1	I	1	0-255	Pan Movement	7127	
2	2	2	2		Pan Fine 16bit	127	
Z	2	2	2	0-255	Fine Control of Pan Movement	7127	
3	3	3	3		TILT Movement 8bit	127	
3	3	3	3	0-255	Tilt Movement	7127	
4	4	4	4		Tilt Fine 16bit	127	
4	4	4	4	0-255	Fine Control of Tilt Movement	7127	
		5	5		Cyan	0	
		٦	٦	0-255	0 → 100%	70	
			6		Cyan Fine	0	
			O	0-255	Fine Cyan Control	70	
		6	7		Magenta	0	
		O	/	0-255	0 → 100%	70	
			8		Magenta Fine	0	
			0	0-255	Fine Magenta Control		
		7	9		Yellow	– 0	
	/		9	0-255	0 → 100%		
			10		Yellow Fine	0	
			10	0-255	Fine Yellow Control	70	
5	5				Red	255	
5	3			0-255	0 → 100%	255	
	6				Red Fine	255	
	O			0-255	Fine Red Control	7233	
6	7				Green	255	
O	/			0-255	0 → 100%	7233	
	8				Green Fine	255	
	0			0-255	Fine Green Control		
7	9				Blue	255	
,	9			0-255	0 → 100%	7233	
	10				Blue Fine	255	
				0-255	Fine Blue Control		
8	11			Mint	255		
				0-255	0 → 100%		
	12				Mint Fine	255	
	12			0-255	Fine Mint Control		
9	13				Amber	255	
,	1 3			0-255	0 → 100%	7233	
	14				Amber Fine	255	
	' ¬			0-255	Fine Amber Control		

	MODE / CH	IANNEL			FUNCTION	DEFAULT	SNAP
Standard	Extended	CMY	CMY Extended	VALUE	Standard	Extended	CMY
10	15	8	11	0-23 24-85	Color Temperature Control Disabled 2400K to 8500K (100K Steps)	0	
				86-255	8500K Color Wheel		
				0	Open		
				1-60	Virtual Gel Swatch Book (See Table Page 35)		
				61-179	No Function		
				400 204	Color Scroll		
11	16	9	12	180-201	CW Rotation Fast to Slow	0	
					Stop ICCW Rotation Slow to Fast		
				230-234			
				230 234	Random Slots		
				235-239		-	
					Medium		
				245-249	Slow		
				250-255			
					Green Shift		
	4 7		4.7	0	Idle		
	17		13	1-127	Full Minus Green to Neutral	0	
				128 129-255	Neutral White Neutral to Full Plus Green		
				129-255	Gobo Wheel 1		
				0-9	Open		
				10-19	Gobo 1		
				20-29	Gobo 2		
				30-39	Gobo 3		
				40-49	Gobo 4		
				50-59	Gobo 5		
				60-69	Gobo 6		
4.2	4.0	4.0	4.4	70-89	Gobo 1 Shake Slow to Fast		V
12	18	10	14	90-109	Gobo 2 Shake Slow to Fast	0	Χ
				110-129	Gobo 3 Shake Slow to Fast		
				130-149 150-169	Gobo 4 Shake Slow to Fast Gobo 5 Shake Slow to Fast		
				170-189	Gobo 6 Shake Slow to Fast		
				190-221	Gobo Wheel Scroll CW Fast to		
					Slow		
				222-223	Stop		
				224-255	Gobo Wheel Scroll CCW Slow to		
					Fast		

	MODE / Ch	IANNEL					
Standard	Extended	CMY	CMY Extended	VALUE	FUNCTION	DEFAULT	SNAP
					Gobo Wheel 1 Gobo Index/Rotation		
4.7	40	4.4	4.5	0-127	Gobo Indexing	. 7	
13	19	11	15	128-189	Gobo Scroll CW Fast to Slow	63	
				190-193	No Rotation		
				194-255	Gobo Scroll CCW Slow to Fast		
					Gobo Wheel 1		
14	20	12	16		Gobo Fine Index	0	
				0-255	Fine Indexing		
					Gobo Wheel 2		
				0-9	Open		
				10-19	Gobo 1		
				20-29	Gobo 2		
				30-39	Gobo 3		
				40-49	Gobo 4		
				50-59	Gobo 5		
				60-69	Gobo 6		
				70-89	Gobo 1 Shake Slow to Fast		
15	21	13	17	90-109	Gobo 2 Shake Slow to Fast	0	Χ
				110-129	Gobo 3 Shake Slow to Fast		
					Gobo 4 Shake Slow to Fast		
					Gobo 5 Shake Slow to Fast		
				170-189	Gobo 6 Shake Slow to Fast		
				190-221	Gobo Wheel Scroll CW Fast to Slow		
				222-223	Stop		
				224-255	Gobo Wheel Scroll CCW Slow to Fast		
					Gobo Wheel 2		
					Gobo Index/Rotation		
16	22	14	18	0-127	Gobo Indexing	63	
10	22	14		128-189	Gobo Scroll CW Fast to Slow	03	
				190-193	No Rotation		
				194-255	Gobo Scroll CCW Slow to Fast		
					Gobo Wheel 2		
17	23	15	19		Gobo Fine Index	0	
				0-255	Fine Indexing		

Standard Extended Extended		MODE / Ch	IANNEL							
18	Standard	Extended	CMY		VALUE	FUNCTION	DEFAULT	SNAP		
18										
18										
128-135										
136-143 Prism/Gobo Macro2 144-151 Prism/Gobo Macro3 152-159 Prism/Gobo Macro4 160-167 Prism/Gobo Macro5 168-175 Prism/Gobo Macro5 176-183 Prism/Gobo Macro7 184-191 Prism/Gobo Macro8 192-299 Prism/Gobo Macro10 208-215 Prism/Gobo Macro11 216-223 Prism/Gobo Macro11 216-223 Prism/Gobo Macro12 224-231 Prism/Gobo Macro13 232-239 Prism/Gobo Macro14 244-247 Prism/Gobo Macro15 248-255 Prism/Gobo Macro15 248-255 Prism/Gobo Macro16 Prism Index/Prism Rotation Prism Rotati										
18										
18										
18										
18										
18										
176-183 Prism/Gobo Macro7 184-191 Prism/Gobo Macro8 192-199 Prism/Gobo Macro10 208-215 Prism/Gobo Macro11 216-223 Prism/Gobo Macro12 224-231 Prism/Gobo Macro13 232-239 Prism/Gobo Macro13 232-239 Prism/Gobo Macro14 240-247 Prism/Gobo Macro15 248-255 Prism/Gobo Macro15 248-255 Prism/Gobo Macro16 Prism Index/Prism Rotation Prism Index/Prism Rotat	18	24	16	20						
192-199 Prism/Gobo Macro9 200-207 Prism/Gobo Macro10 208-215 Prism/Gobo Macro11 216-223 Prism/Gobo Macro12 224-231 Prism/Gobo Macro13 232-239 Prism/Gobo Macro14 240-247 Prism/Gobo Macro15 248-255 Prism/Gobo Macro15 248-255 Prism/Gobo Macro16 Prism Index/Prism Rotation 0-127 Prism Index/Prism Rotation Prism Index/Prism Rotation 194-255 Prism Rotation CW Fast to Slow 190-193 No Rotation CW Slow to Fast Prism Fine Index Rotation CW Fine Index Rotation CO Fin	10	2-7	10	20						
200-207 Prism/Gobo Macro10 208-215 Prism/Gobo Macro11 216-223 Prism/Gobo Macro12 224-231 Prism/Gobo Macro13 232-239 Prism/Gobo Macro14 240-247 Prism/Gobo Macro16 Prism Index/Prism Rotation Prism Index/Prism Rotation 0-127 Prism/Gobo Macro16 Prism Index/Prism Rotation Prism Index/Prism Rotation 0-127 Prism Index/Prism Rotation Prism Index/Prism Rotation 194-255 Prism Rotation CW Fast to Slow 190-193 No Rotation Rotation No Rotation 194-255 Prism Rotation Prism Index Rotation 194-255 Prism Index/Prism Rotation Prism Index Rotation Prism Index Rotation Prism Index Rotation 194-255 Prism Index Rotation Prism I										
208-215 Prism/Gobo Macro11 216-223 Prism/Gobo Macro12 224-231 Prism/Gobo Macro13 232-239 Prism/Gobo Macro14 240-247 Prism/Gobo Macro15 248-255 Prism/Gobo Macro15 248-255 Prism/Gobo Macro16 Prism Index/Prism Rotation 0-127 Prism Index/Prism Rotation 0-127 Prism Index/Prism Rotation 0-127 Prism Rotation CCW Flow to Fast Prism Rotation CCW Slow to Fast Prism Rotation C-255 Prism Rotation C-25										
216-223 Prism/Gobo Macro12 224-231 Prism/Gobo Macro13 232-239 Prism/Gobo Macro14 240-247 Prism/Gobo Macro15 248-255 Prism/Gobo Macro15 248-255 Prism/Gobo Macro16 Prism Index/Prism Rotation 0-127 Prism Index/Prism Rotation 0-127 Prism Index/Prism Rotation 0-127 Prism Rotation CW Fast to Slow 190-193 No Rotation 190-193 No Rotation 190-193 No Rotation Prism Rotation CCW Slow to Fast Prism Rotation CCW Slow to Fast Prism Rotation CCW Slow to Fast Prism Index Rotation 0-255 Fine Indexing Focus Continuous Adjustment Near to 1270 Far Focus Fine O Continuous Adjustment Fine Continuous Continuo										
19 25 17 21 28 19 24 20 25 22 29 20 25 23 30 21 26 24 31 22 27 24 31 22 27 27 27 27 27 27 2										
232-239 Prism/Gobo Macro14 240-247 Prism/Gobo Macro15 248-255 Prism/Gobo Macro15 248-255 Prism/Gobo Macro16 Prism Index/Prism Rotation 0-127 Prism Index/Ing 128-189 Prism Rotation CW Fast to Slow 190-193 No Rotation 194-255 Prism Rotation CCW Slow to Fast Prism Fine Index Rotation 0-255 Prism Fine Index Rotation 0-255 Fine Indexing Focus Fo										
240-247 Prism/Gobo Macro15 248-255 Prism/Gobo Macro16 Prism Index/Prism Rotation 0-127 Prism Index/Prism Rotation 128-189 Prism Rotation CW Fast to Slow 190-193 No Rotation 194-255 Prism Rotation CW Slow to Fast Prism Fine Index Rotation 194-255 Prism Rotation CW Slow to Fast Prism Fine Index Rotation 1270 Focus 1270 Focus 1270 Focus Fine 1270 Focus Fine										
248-255 Prism/Gobo Macro16 Prism Index/Prism Rotation O-127 Prism Index/Prism Rotation Prism Index/Prism Rotation O-127 Prism Indexing Typ-193 No Rotation Typ-194 No Rotation Typ-195 Prism Rotation CCW Slow to Fast Prism Fine Index Rotation O-255 Fine Indexing Focus Focus										
Prism Index/Prism Rotation										
19					248-255					
19										
190-193 No Rotation 194-255 Prism Rotation CCW Slow to Fast Prism Fine Index Rotation 0-255 Fine Indexing Focus Continuous Adjustment Near to Far Focus Fine 0 1270 Far Focus Fine 1270 Far Fa						Prism Indexing				
194-255 Prism Rotation CCW Slow to Fast	19	25	17 21	17 21	17	21				
26 22										
20 27 18 23 0-255 Fine Indexing Focus					194-255					
20 27 18 23		26		22						
20		20		22	0-255	Fine Indexing				
21 28 19 24										
21	20	27	18	23	0-255		1270			
22 29 20 25	21	7Q	10	24		Focus Fine	0			
20 25	۷ ا	20	19	∠ '1	0-255	Continuous Adjustment Fine	U			
23 30 21 26 Zoom Adjustment Small to Big Zoom Fine 0-255 Zoom Adjustment Fine Shutter, Strobe O-31 Shutter Closed 32-63 No Function (Shutter Open) 64-95 Strobe Effect Slow to Fast 96-127 No Function (Shutter Open) 128-159 Pulse-Effect in Sequences 160-191 No Function (Shutter Open) 192-223 Random Strobe Effect Slow to Fast	22	20	20	25			127			
24 31 22 27 26 O-255 Zoom Adjustment Fine Shutter, Strobe O-31 Shutter Closed 32-63 No Function (Shutter Open) 64-95 Strobe Effect Slow to Fast 96-127 No Function (Shutter Open) 128-159 Pulse-Effect in Sequences 160-191 No Function (Shutter Open) 192-223 Random Strobe Effect Slow to Fast		27	20	23	0-255		1 ∠ /			
24 31 22 27 Shutter Closed 32-63 No Function (Shutter Open) 64-95 Strobe Effect Slow to Fast 96-127 No Function (Shutter Open) 128-159 Pulse-Effect in Sequences 160-191 No Function (Shutter Open) Random Strobe Effect Slow to Fast 192-223 Random Strobe Effect Slow to Fast	22	30	21	26			Ω			
24 31 22 27 Shutter Closed 32-63 No Function (Shutter Open) 64-95 Strobe Effect Slow to Fast 96-127 No Function (Shutter Open) 128-159 Pulse-Effect in Sequences 160-191 No Function (Shutter Open) Random Strobe Effect Slow to Fast	23	50	Z I	20	0-255		U			
32-63 No Function (Shutter Open) 64-95 Strobe Effect Slow to Fast 96-127 No Function (Shutter Open) 128-159 Pulse-Effect in Sequences 160-191 No Function (Shutter Open) Random Strobe Effect Slow to Fast										
24 31 22 27 64-95 Strobe Effect Slow to Fast 96-127 No Function (Shutter Open) 50 X 128-159 Pulse-Effect in Sequences 160-191 No Function (Shutter Open) Random Strobe Effect Slow to Fast										
24 31 22 27 96-127 No Function (Shutter Open) 50 X 128-159 Pulse-Effect in Sequences 160-191 No Function (Shutter Open) Random Strobe Effect Slow to Fast										
128-159 Pulse-Effect in Sequences 160-191 No Function (Shutter Open) 192-223 Random Strobe Effect Slow to Fast										
128-159 Pulse-Effect in Sequences 160-191 No Function (Shutter Open) Random Strobe Effect Slow to Fast	24	31	22	27		l ·	50	X		
192-223 Random Strobe Effect Slow to Fast	24 51	٠,٠	~~	۷,			50	^		
					160-191					
					192-223					
					224-255	No Function (Shutter Open)				

MODE / CHANNEL		VALUE					
Standard	Extended	CMY	CMY Extended	VALUE	FUNCTION	DEFAULT	SNAP
25	32	23	28	0-255	Dimmer Intensity 0 → 100%	0	
26	33	24	29	0-255	Dimmer Fine 0-255 Dimmer Fine Adjustment		
	34		30	121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142-255	Dim Modes Standard Stage TV Architectural Theatre Stage 2 Dimmer Delay Time 0.0s 0.1s 0.2s 0.3s 0.4s 0.5s 0.6s 0.7s 0.8s 0.9s 1.0s 1.5s 2.0s 3.0s 4.0s 5.0s 6.0s 7.0s 8.0s 9.0s	0	X
27	35	25	31	0-191 192-223 224-255		0	
	36		32	0-255	lris Fine Iris Fine Adjustment	0	
28	37	26	33	0-255	Frost Open to Full Frost	0	
29	38	27	34	0-7 8-255	Animation Wheel Open Animation Min to Max		

MODE / CHANNEL							
Standard	Extended	CMY	CMY Extended	VALUE	FUNCTION	DEFAULT	SNAP
					Animation Index Rotation		
				0-127	Animation Indexing		
70				128-189	Animation Rotation CW Fast to		
30	39	28	35		Slow		
				190-193	No Rotation		
				194-255	Animation Rotation CCW Slow to Fast		
					Pan / Tilt and Color Speed		
	4.0		7.	0-225	Max to Min Speed	•	
	40		36	226-235	Blackout by Movement	0	
					Blackout by All Wheel Changing		
				246-255	No Function		
				0.10	Control		
				0-19 20-29	Color Change Normal		
				20-29	Color Change to Any position Color/Gobo Change to Any		
				30-39	Position Change to Any		
				40-44	Fan Mode Studio		
				45-49	Fan Mode Mute		
				50-59	Fan Mode Low		
				60-69	Fan Mode High		
				70-79	Fan Mode Auto		
				80-84	All Motor Reset		
				85-87	Pan / Tilt Reset		
				88-90	Color Reset		
				91-93	Gobo Reset		
				94-96	Focus and Zoom Reset		
				97-99	Other Motor Reset		
				4.00	Refresh Rate (Hz)		
31	41	29	37	100	900	0	X
				101	910		
				102 103	920 930		
				103	940		
				104	950		
				106	960		
				107	970		
				108	980		
				109	990		
				110	1000		
				111	1010		
				112	1020		
				113	1030		
				114	1040		
				115	1050		
				116	1060		
				117	1070		

	MODE / CH	IANNEL					
Standard	Extended	CMY	CMY Extended	VALUE	FUNCTION	DEFAULT	SNAF
					Refresh Rate (Hz)		
				118	1080		
				119	1090		
				120	1100		
				121	1110		
				122	1120		
				123	1130		
				124	1140		
				125	1150		
				126	1160		
				127	1170		
				128	1180		
				129	1190		
				130	1200		
				131	1210		
				132	1220		
				133	1230		
				134	1240		
				135	1250		
				136	1260		
	41	29	37	137	1270		X
31				138	1280	0	
<i>J</i> 1	41	29	37	139	1290		^
				140	1300		
				141	1310		
				142	1320		
				143	1330		
				144	1340		
				145	1350		
				146	1360		
				147	1370		
				148	1380		
				149	1390		
				150	1400		
				151	1410		
				152	1420		
				153	1430		
				154	1440		
				155	1450		
				156	1460		
				157	1470		
				158	1480		
				159	1490		
				160	1500		

MODE / CHANNEL							
Standard	Extended	CMY	CMY	VALUE	FUNCTION	DEFAULT	SNAP
Standard Extended		CITT	Extended				X
					Refresh Rate (Hz)		
				161	2500		
				162	4000		
				163	5000		
				164	6000		
				165	10,000		
				166	15,000		
				167	20,000		
				168	25,000		
				169-200	Idle		
		201-210 Dimmer Curve Linear (defau	Dimmer Curve Linear (default)				
			211-220 Dimmer Curve Square 221-230 Dimmer Curve Inverse Square	211-220	Dimmer Curve Square		
		41 29 37 Internal Prog (Scene 1-8)		231-240	Dimmer Curve S-Curve	0	X
31	41		37	241	Internal Program 1		
				242	Internal Program 2		
				272	(Scene 9-16)		
				243	Internal Program 3		
				213	(Scene17-24)		
			244 Internal Program 4	_			
					(Scene25-32)		
				245	Internal Program 5		
					(Scene33-40)		
				246	Internal Program 6		
				240	(Scene41-48)		
				247	Internal Program 7		
					(Scene49-56)		
				248-255	ldle		

REMOTE DEVICE MANAGEMENT (RDM)

NOTE: For RDM to work properly, RDM enabled equipment must be used throughout the entire system, including DMX data splitters and wireless systems.

Remote Device Management (RDM) is a protocol that sits on top of the DMX512 data standard for lighting, allowing the DMX systems of the device to be managed, modified, and monitored remotely (hence, remote device management). This protocol is ideal for fixtures installed in locations that are not easily accessible.

With RDM, the DMX512 system becomes bi-directional, allowing a compatible RDM enabled controller to send out a signal to devices on the wire, as well as allowing the fixture to respond (known as a GET command). The controller can then use it's SET command to modify settings that would typically have to be changed or viewed directly via the unit's display screen, including the DMX Address, DMX Channel Mode, and Temperature Sensors.

Model	RDM Code	Device Model ID Decimal/Hexdecimal	Personality ID
FUZE SPOT	0×22A6	0002	Standard(1) Extend(2) CMY Standard (3) CMY Extend (4)

FIXTURE RDM INFORMATION:

Please be aware that not all RDM devices support all RDM features, and therefore it is important to check beforehand to ensure that the equipment that you are considering includes all the features that you require.

The following parameters are accessible in RDM on this device:

[0x0011] Proxied Device Count [0x0200] Sensor Definition [0x0201] Sensor Value [0x0080] Device Model Description [0x0081] Manufacturer Label [0x0082] Device Label [0x00E0] DMX Personality	[0x0600] Pan Invert [0x0601] Tilt Invert [0x0602] Pan Tilt Swap [0x0500] Display Invert [0x0501] Display Level [0x0603] Realtime Clock [0x1010] Power State [0x1031] Preset Playback
[0x0400] Device Hours	[0x0122] Default Slot Value
[0x0015] Comms Status	[0x00B0] Language
[0x0031] Status ID Description [0x0032] Clear Status ID	[0x00A0] Language Capabilities [0x00C2] Boot Software Version Label
[0x0401] Lamp Hours	[0x00C2] Boot Software Version ID
[0x0402] Lamp Strikes	[0x0070] Product Detail ID List
[0x0403] Lamp State	[0x0030] Status Messages
[0x0404] Lamp Mode	[0x1001] Reset Device
[0x0405] Device Power Cycles	[0x0016] Undefined PID [0x0016,(22)]

COLOR TEMPERATURE TABLE

VALUE	COLOR TEMP (K)	VALUE	COLOR TEMP (K)
24	2400	55	5500
25	2500	56	5600
26	2600	57	5700
27	2700	58	5800
28	2800	59	5900
29	2900	60	6000
30	3000	61	6100
31	3100	62	6200
32	3200	63	6300
33	3300	64	6400
34	3400	65	6500
35	3500	66	6600
36	3600	67	6700
37	3700	68	6800
38	3800	69	6900
39	3900	70	7000
40	4000	71	7100
41	4100	72	7200
42	4200	73	7300
43	4300	74	7400
44	4400	75	7500
45	4500	76	7600
46	4600	77	7700
47	4700	78	7800
48	4800	79	7900
49	4900	80	8000
50	5000	81	8100
51	5100	82	8200
52	5200	83	8300
53	5300	84	8400
54	5400	85	8500

VIRTUAL GEL SWATCH BOOK

VALUE	FILTER#	COLOR	VALUE	FILTER#	COLOR
1	7	Pale Yellow	31	126	Mauve
2	103	Straw	32	49	Medium Purple
3	151	Gold Tint	33	58	Lavender
4	100	Spring Yellow	34	199	Palace Blue
5	10	Medium Yellow	35	119	Dark Blue
6	101	Yellow	36	132	Medium Blue
7	104	Deep Amber	37	120	Deep Blue
8	15	Deep Straw	38	165	Daylight Blue
9	179	Loving Amber	39	161	Slate Blue
10	21	Gold Amber	40	118	Light Blue
11	105	Orange	41	68	Sky Blue
12	158	Deep Orange	42	143	Pale Navy Blue
13	22	Dark Amber	43	131	Marine Blue
14	778	Millennium Gold	44	115	Peacock Blue
15	135	Deep Golden Amber	45	172	Lagoon Blue
16	24	Scarlet	46	116	Medium Blue Green
17	106	Primary Red	47	90	Dark Yellow Green
18	26	Bright Red	48	139	Primary Green
19	27	Medium Red	49	122	Fern Green
20	19	Fire	50	89	Moss Green
21	157	Pink	51	124	Dark Green
22	36	Medium Pink	52	88	Lime Green
23	111	Dark Pink	53	138	Pale Green
24	128	Bright Pink	54	203	Quarter CT Blue
25	148	Bright Rose	55	202	Half CT Blue
26	332	Special Rose Pink	56	201	FULL CT Blue
27	793	Vanity Fair	57	200	Double CT Blue
28	113	Magenta	58	206	Quarter CT Orange
29	46	Dark Magenta	59	205	Half CT Orange
30	48	Rose Purple	60	204	FULL CT Orange

ERROR CODES

E	Error Codes subject to change without notice.					
ERROR CODES	DESCRIPTION					
PAN Er	Movement is not located in the default position after the reset. These messages will appear after a fixture reset if the magnetic-indexing circuit malfunctions (sensor failed, or					
TILT Er	magnet is missing) or there is a motor failure (defective motor or a defective motor IC drive on the main PCB). This error may also be displayed if the head/yoke was blocked during a reset function.					
RotGobo						
RotGobo2						
Iris						
RotGoboIndex						
RotGobo2Index	Movement is not located in the default position after the reset.					
Animation	These messages will appear after a fixture reset if the magnetic-indexing circuit malfunctions (sensor failed, or					
Anima.Index	magnet is missing) or there is a motor failure (defective motor					
Zoom	or a defective motor IC drive on the main PCB).					
Focus						
Frost						
Prism						
PrismIndex						
HeadTemp						
CoolFan1						
CoolFan2						
CoolFan3	These messages will appear if there is a temperature and/or fan malfunction.					
CoolFan4						
BaseTemp						
BaseFan						

SPECIFICATIONS

SOURCE

305W 6,500K RGBMA LED Engine 30,000 Hour Average LED Life*

*Test lab conditions. May vary depending on several factors including but not limited to: Environmental Conditions, Power/Voltage, Usage Patterns (On-Off Cycling), Control, and Dimming.

PHOTOMETRIC DATA

10,100 Total Lumen Output CRI 92

Zoom Range 7° - 42° Beam Angle7.5° - 39.9° Field Angle 8.6° - 44.2°

EFFECTS

Motorized Zoom Variable Frost Filter 4 Facet Prism Motorized Iris Variable 16-bit Dimming Curve Modes High Speed Electronic Shutter and Strobe Pan Angle: 540° (630°) Tilt Angle 270°

COLOR

RGBMA Color Array CMY Emulation Variable CCT 2400K - 8500K Green/Magenta Shift Virtual Gel Swatch Book

GOBOS

2x 6 Rotating / Indexing Interchangeable Glass Gobos Animation Wheel

CONTROL / CONNECTIONS

4 DMX Channel Modes (RGBMA 31 / 41) (CMY 29 / 37) 16-bit Pan, Tilt, and Dimming Control DMX Adjustable LED Frequency DMX, RDM Protocol Support 4 Button Touch Control Panel Full Color 180° Reversible LCD Menu Display Locking 5pin XLR Connector In/Out IP65 Locking Power Connector In/Out With Wired Digital Communication Network

SIZE / WEIGHT

Length: 16.1" (408.0mm) Width: 10.1" (256.0mm)

Vertical Height: 27.5" (698.0mm)

Weight: 46.3 lbs. (21kg)

ELECTRICAL / THERMAL

AC 100-240V - 50/60Hz 466W Max Power Consumption 14°F to 113°F (-10°C to 45°C) BTU/hr (+/- 10%) 1589.06


APPROVALS / RATINGS

CE | cETLus | IP20

Specifications and improvements in the design of this unit and this manual are subject to change without notice.

DIMENSIONAL DRAWINGS


Drawings not to scale.



Specifications and improvements in the design of this unit and this manual are subject to change without notice.

DIMENSIONAL DRAWINGS - SNOOT ATTACHED

Drawing not to scale.



Specifications and improvements in the design of this unit and this manual are subject to change without notice.

OPTIONAL ACCESSORIES

ORDER CODE	ITEM
TRIGGER CLAMP	Heavy Duty Wrap Around Hook Style Clamp
SIP126	5 ft. (1.5m) IP65 Twist Lock Power Link Cable
AC5PDMX5PRO	5 ft. (1.5m) 5pin PRO DMX Cable
	Additional Cable Lengths Available

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RADIO FREQUENCY INTERFERENCE WARNINGS & INSTRUCTIONS

This product has been tested and found to comply with the limits as per Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device uses and can radiate radio frequency energy and, if not installed and used in accordance with the included instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following methods:

- Reorient or relocate the device.
- Increase the separation between the device and the receiver.
- Connect the device to an electrical outlet on a circuit different from which the radio receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

