
AT8474 LOW-PROFILE ISOLATION MOUNT INSTALLATION INSTRUCTIONS MOUNTING DIMENSIONS

A. 1/16" (1.5 mm) pilot holes 3 places on 1.57" (40.0 mm) circle.

B. 1.00" (25.4 mm) hole through the mounting surface.

C. Outside edge of mount, 2.06" (52.4 mm) diameter.



Drawing not actual size.

- The AT8474 mount can be mounted either above or below the table surface.
- Locate the center of the mounting location and mark it. Allow enough clearance to accommodate the AT8474 mount on the desired surface and make certain there are no physical obstructions below the desired location.
- 3. Locate the three mounting screw holes and mark them.
- 4. Using a 1" hole saw, drill the through-hole for the microphone body. (Note: although a 1" drill bit will work, a hole saw provides for a cleaner hole and is less likely to damage the table surface.)
- Using a ¹/₁₆" (1.5 mm) drill bit, drill three pilot holes for the mounting screws. (If mounting below the table surface, be certain **NOT** to drill pilot holes through the table.)
- 6. Place the AT8474 mount over the hole and partially tighten the three screws. Then place the microphone in the AT8474 so that the microphone's power module (base) extends through the AT8474 mount into the hole. Tighten all three screws evenly. For maximum security, the screws should be tight enough to ensure that the microphone is held securely in place and can not be removed without loosening the screws.
- 7. If mounting the AT8474 mount below the surface of the table, slide the rubber trim ring over the microphone (above the table surface) and seat it between the microphone and the sides of the hole for a finished appearance. (If mounting the AT8474 above the surface of the table, you may also choose to use the trim ring beneath the surface of the table, for added attenuation of noise, shock and vibration.)
- 8. After installing the microphone, assure maximum shock mount effectiveness by providing some slack in the connecting cable. The cable can be secured to the table with a standard wire clip or cable tie (not included).

