

Creative audio solutions in cool little boxes.

## Phantom **T**48V Phantom Power Supply



Different condenser microphones specify different amounts of required phantom power. As a rule these ratings can range from 48 volts all the way down to 9 volts. Fortunately there is some flexibility in terms of matching phantom voltage to your mic. A rough rule of thumb would be "more is better." For example, a 24-volt condenser mic will run perfectly on 48 volts. In fact mics rated at as little as 9 volts can often operate on 48 volts,but you should check with the manufacturer first. Conversely, a mic will generally perform best driven by not less than its rated voltage so,for a 48V mic,you would obtain best results with 48 volts of phantom power.



a. Plug the AC adapter into the 18V AC connector and plug the other end into a 120V AC power outlet.


Mic Input

Mic Output

- b. Connect mic cable to the female XLR Input connector.
- c. Using another mic cable,patch from the adjacent (male)
  Output connector to a mic input on the mixer.

## **Specifications**

- Power: 18VAC (Adapter included)Output Phantom Power: 48VDC +/- 2V
- Input Connector: XLR female
  Output connector: XLR male
- Output Noise:-71 dBV
- Frequency Response: 10Hz 25kHz
- Current Drain: 14mA
- Size: 5.25 x 2.75 x 1.75 inches (130 x 74 x 45mm)
- Weight: 1lb (450g)



Designed & Distributed By



support@artproaudio.com www.artproaudio.com